



Spare Parts

H0325-S	Tail Rotor Shaft With Tail Hub Assembled x 1pc.
HC153-S	Cup Point Set Screws M4x6mm x 1pc.
HC335-S	Tail Hub Oring x 2pcs.
H0327-S	Aluminum Tail Grip x 2pcs.
HC411-S	Bearing $\varnothing 5 \times \varnothing 10 \times 4 \text{ mm}$ x 4pcs.
HC435-S	Thrust Bearing $\varnothing 5 \times \varnothing 10 \times 4 \text{ mm}$ x 2pcs.
HC096-S	Button Head Cap Screw M4x6mm x 2pcs.
HC004-S	Socket Head Cap Screw M2x6mm x 2pcs.
HC330-S	Spacer $\varnothing 5 \times \varnothing 9 \times 0,75 \text{ mm}$ x 2pcs.
HC349-S	Spacer $\varnothing 7,5 \times \varnothing 10 \times 0,5 \text{ mm}$ x 2pcs.


Tail Rotor Hub Assembly

Already Assembled



Tail Pitch Slider Link Assembly (Not included in H0324-S)

Already Assembled



Bottom Head Cap Screw M4x6mm



Socket Head Cap Screw M2x6mm

