

GOBLIN 380 STRETCH KIT to 420

Please read this user manual carefully, it contains instructions for the correct assembly of the KIT.

Please refer to the website www.goblin-helicopter.com for updates and other important information. Thank You.



It is recommended to use a smaller motor pulley with the new rotor size.

Starting from a typical G380 setup, you have to consider a motor pulley with 1 or 2 teeth less for G420.


Assemble the components here below following the manual of the original Kit:











Refer to the following instructions to assemble the tail belt guide system. This solution is necessary with the new front tail pulley.

